



Notes:

1. Use 5/8 flat head wood screws to secure sand paper.
2. Apply self-adhesive cork drawer liner to bottom of sanding block.
3. Slots cut with 0.030 kerf band saw blade.
4. Cut standard sand paper sheet in thirds length-wise to fit sanding block.
5. To affix sanding paper to block: insert first end in 45 deg slot, wrap paper around bottom of block, insert second end in screw slot till paper is snug, tighten screws.
6. All dimensions in inches.



Product Sanding Block		Date 4/8/2018
Size A	Page 1 of 1	Drawn By Stephen Graf